

#GENERALCAN/CSA / US/ASME (SEE APPLIED CODE), ALL PROVINCIAL/STATE AND LOCAL

CODES.

PLUMB HDISTWAY- DUE TO CLOSE RUNNING CLEARANCES OWNER/AGENT MUST ENSURE THAT HOISTWAY AND PIT (WHERE PROVIDED) ARE LEVEL, PLUMB AND SQUARE AND ARE IN ACCORDANCE WITH THE DIMENSIONS ON THESE DRAWINGS.

<u>AD CLEARANCE</u> DWNER/AGENT MUST ENSURE MINIMUM CANCE IS IN COMPLIANCE WITH CODES.

CONSTRUCTION SITE— OWNER/AGENT TO PROVIDE ALL MASONRY,
CARPENTRY AND DRYWALL WORK AS REQUIRED AND SHALL PATCH AND
MAKE GOOD (INCLUDING FINISH PAINTING) ALL AREAS WHERE
WALLS/FLOORS MAY REQUIRE TO BE CUT, DRILLED OR ALTERED IN
ANY WAY TO PERMIT THE PROPER INSTALLATION OF THE LIFT.

STOMER TO VERIFY ALL DIMENSIONS AND REPORT ANY

WALL LOADS— STRUCTURAL ENGINEER TO ASSURE AND SHAFT WILL SAFELY SUPPORT ALL LOADS INTO EQUIPMENT. REFER TO THE TABLES ON THIS DADS IMPOSED BY THE EQUIPMENT.

RE REQUIRED— SUITABLE LINTELS MUST BE PROVIDED T. DOOR FRAMES ARE NOT DESIGNED TO SUPPORT LOADS.

*MACHINE ROOM

LOCATION / ACCESS__ MACHINE ROOM LOCATED AT THE LOWEST

LEVEL ADJACENT TO HOISTWAY, UNLESS SHOWN OTHERWISE ON

LAYOUT DRAWINGS. FIELD ADJUSTMENT BY INSTALLER MAY BE

NECESSARY TO MEET JOB SITE CONDITIONS OR REGULATIONS.

MACHINE ROOM DOOR IS TO BE LOCKABLE AND IS TO MEET THE

MACHINE ROOM DOOR IS TO BE LOCKABLE AND IS TO MEET THE U THE

MUTUK & EWUT 30 AMPS 30 AMPS 208 VOLT THREE PHASE 15.6 AMP	WITTIN . FOUTE 60 AMPS 40 AMPS 230 VOLT SINGLE PHASE 21	SIZE VOLTS PHASE	DISCONNECT TIME DELAY	
PHASE 15.6 AMPS	SE 21 AMPS	AMPERAGE		

POWER SUPPLY- (SEE SPECIFICATIONS) LOCKABLE FUSED DISCONNECT WITH AUXILIARY CONTACT TO BRAKE THE BATTERY FEED, OR CIRCUIT BREAKERS WITH A 3-POLE BREAKER FOR BATTERY FEED REQUIRED, IN COMPLIANCE WITH ELECTRICAL CODE, AS FOLLOWS: (LOCATED DO WALL ON LOCK JAMB SIDE OF MACHINE ROOM DOOR) PERMANENT POWER- BEFORE INSTALLATION CAN BEGIN, PERMANENT POWER MUST BE SUPPLIED.

LIGHTING- OWNER/AGENT TO ENSURE AT LEAST 9.3 FTC OR 100 LUX AMBIENT LIGHTING OVER LIFT AREA.

*ENTRANCES

FASCIA PANEL BELOW UPPER LEVEL ENTRANCE— WHERE REQUIRED,
FASCIA PANEL MUST BE FASTENED TO A SOLID WALL AND BE
PERPENDICULAR TO THE FLOOR AND WALLS. HOISTWAY
FASCIA IS NOT SELF-SUPPORTING FOR LONG, CONTINUOUS
RUNS VOID OF ENTRANCES. ADEQUATE SUPPORT FOR THE
FASCIA MUST BE PROVIDED.
ENTRANCE ASSEMBLIES— ENTRANCE ASSEMBLIES MUST BE ADJUSTED
TO ALIGN WITH PLATFORM AND INTERLOCK EQUIPMENT. OTHERS TO
ALLOW AN ADEQUATE ROUGH OPENING.
RETURN WALLS. RETURN WALLS AT ENTRANCES MUST BE BUILT-IN
BY OTHERS AFTER ENTRANCE ASSEMBLIES ARE IN PLACE. ENTRANCE
ASSEMBLY MUST BE SECURELY FASTENED TO WALLS BY ELEVATOR
CONTRACTOR.

TION IS SUBJECT TO CHANGE. RENCE OUR ON-LINE DRAWINGS AT ACOM FOR THE MOST RECENT UPDATES

0 Savaria.